Futaba In-mold measurement mold marshaling system Injection Molding Monitoring System MVS08

Instruction Manual for Connection Cable

Thank you very much for purchasing the products of Futaba Corporation. Please read this instruction manual thoroughly and use it for a long time.

■ Handling Precautions



Warning

Be sure to unplug the power cable from the outlet when installing or connecting the cable. Failure to do so may cause an electric shock or malfunction.



Warning

Do not use a cable that is broken or damaged in the cable sheath. Failure to do so may cause a fire, electric shock, damage to the



Do not splash water on the sensors, amplifiers, junction box, or connection cables. Failure to do so may result in electric shock or damage to the equipment.

1. SPECIFICATIONS LIST < Production code: WCI0130-6P N-MVS08>

Number of points measured	Up to 1 point
Compatible device	Pressure measuring device: MPS01A
Cable length	3m
Environmental resistance Ambient temperature	0~+40°C
Weight	Approx. 140g

2. Connection list... Refer also to the system configuration diagram on the back

MVS08	Co
Display	MVS08 side
СН1~СН8	No indication (p

Connection cable		
MVS08 side	MPS01A end	
No indication (plug)	24V	
	GND	
	TRG IN	
<u> </u>	COM IN	
	ANALOG+	
	ANALOG -	

MPS01A
Display
B1
A1
B2
В3
В6
A6

3. Connecting to MVS08 Unit

Plug the connecting cable into the connector on MVS08.

There is a rotation-stop. Screw the plug to the right or left to find the fitting position, and then insert it all the way in.

FUTABA CORPORATION

http://www.futaba.co.jp/precision/mold_marshall/index

