

# Futaba In-mold measurement mold marshaling system Injection Molding Monitoring System MVS08

## Instruction Manual for Connection Cable

Thank you very much for purchasing the products of Futaba Corporation. Please read this instruction manual thoroughly and use it for a long time.

### ■ Handling Precautions



**Warning**

Be sure to unplug the power cable from the outlet when installing or connecting the cable.  
Failure to do so may cause an electric shock or malfunction.



**Warning**

Do not use a cable that is broken or damaged in the cable coating.  
Failure to do so may cause a fire, electric shock, damage to the




**Caution**

Do not splash water on the sensors, amplifiers, junction box, or connection cables.  
Failure to do so may result in electric shock or damage to the equipment.

### 1. SPECIFICATIONS LIST < Product code: WCI0820-MPS08 N-MVS08>

Number of points measured	Up to 8 points
Compatible device	Pressure measuring amplifier: MPS08
Cable length	2m
Environmental resistance	0~+40°C
Ambient temperature	
Weight	Approx. 310g

### 2. Connection list... Refer also to the system configuration diagram on the back



\* Be sure to connect the cable's CH1. Otherwise, a trigger signal will not be input and measurement will not be possible.

### 3. Connecting to MVS08 Unit

Plug the connecting cable into the connector on MVS08. There is a rotation-stop. Screw the plug to the right or left to find the fitting position, and then insert it all the way in.

# System configuration diagram for MVS08 injection molding monitoring system and MPS08 pressure measuring amplifier set

